



NOTE 1:  
DEAERATOR OVERFLOW ONLY  
PERMITTED TO GO TO  
CONDENSATE TANK IF THE  
CONDENSATE TANK IS A ASME  
CODE TANK WITH SAME MAWP  
AS THE DEAERATOR.

NOTE:  
FOR COMPLETE PIPING SEE  
REFERENCED DETAILS.

# BASIC FLOW DIAGRAM - CONDENSATE AND BOILER FEEDWATER

NTS

DETAIL TITLE / CONDENSATE, BOILER FEEDWATER, BLOWOFF, CHEMICAL FEED, WATER SAMPLE